



WorkCentre 5645/5655 Online Support
Solution Print the System Configuration Report

Make sure Long Edge Feed (LEF) 8.5 x 11 paper is loaded in a paper tray. If paper is not loaded, the machine will be unable to print the report.

1. Press the [Machine Status] button on the Control Panel. The Machine Status screen will be displayed.



2. Select the [Print Reports] button on the Touch Screen.
3. Select the [Print System Configuration Report] button. The report will print.
4. Select the [Close] button to return to the default screen.